

FREQUENCY	WHAT TO DO		
VISUAL INSPECTION (EVERY MONTH)	Identify any risks stemming from vandalism, intensive use or unusual weather		
	Check for missing or broken parts		
	Make sure that all protective covers are in place		
	Inspect surfacing below and around equipment		
FUNCTIONALITY INSPECTION (EVERY MONTH)	Check that the equipment, or the part concerned is operating correctly		
	Check all fixings, joints and stability of the equipment and tighten or replace if necessary		
	Check all parts for wear and tear and replace if necessary		
	Thorough cleaning of equipment and any stainless steel parts with water and detergent		
COMPREHENSIVE INSPECTION (EVERY 6 MONTHS)	All of the above plus:		
	Inspect the anchoring system		
	Inspect any moving, mechanical and electrical parts are operating correctly		
	Check overall condition of any paintwork or galvanizing – repaint / touch up if necessary		

Spitfire R	oad, Old Sarum, Salisb	ury	2	
Wil	tshire, SP4 6GB, UK			
Tel: +44 (0)1722 349 793			-anr	
www.fahr-industries.com			U III	
This document, including the copyright therein, is the property of Fahr Industries Ltd and may not be utilised for any purpose or reproduced, or transmitted to any third party without prior written consent.				
\mathbf{F}	All Dimensions in mm	1 of 1	Not To Scale	
Title	FS2013 - Sit-In Car Spring Rocker			
Drg By	Richard Willstrop	Date	16/11/20	